


TARGET

APPLY LABEL



To set up, fold tabs as shown.

Target can be adjusted at folds.

See Rules Booklet for instruction on how to use.

Any questions? Call Mattel Consumer Affairs (800) 421-2887.


(Alaska and Hawaii residents phone (213) 978-6128, 6129, 6130 or 6133.)



INTERLOCKER™ ASSEMBLY INSTRUCTIONS

CONTENTS:

Two "AA" alkaline and one 9 volt alkaline batteries required (not included).



NOTE: PLACE NUMBERED LABELS AS INDICATED. PLACE UNNUMBERED LABELS AT YOUR OWN DISCRETION.



4155-0920G1






90-DAY LIMITED WARRANTY

Mattel Toys warrants to the original consumer purchaser of any toy product it manufactures that the product will be free from defects in material or workmanship for 90 days (unless otherwise specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase to either your local dealer or, postage prepaid, to Consumer Adjustment Center, 15930 E. Valley Boulevard, City of Industry, CA 91744 for replacement or refund at our option. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty does not cover damage resulting from accident, misuse or abuse. **Valid only in U.S.A.**

Send only product to the address listed above. Send all correspondence to Consumer Relations, 5150 Rosecrans Avenue, Hawthorne, California 90250 or you may phone us toll-free at (800) 421-2887 (Alaska and Hawaii residents phone (213) 978-6128, 6129, 6130, or 6133).

CAPTAIN POWER and associated trademarks are owned by Landmark Entertainment Group, used under license by Mattel. © Landmark Entertainment Group 1987. **PRINTED IN HONG KONG.** All Rights Reserved.

ASSEMBLE INTERLOCKER AND APPLY LABELS



Push down on throne until it locks. Action figure sold separately.

